

## P032B: KNOCK SENSOR 3 CIRCUIT RANGE/PERFORMANCE (BANK 1)

### OVERVIEW

<b>Severity</b>	:		High
<b>DIY Difficulty Level</b>	:		Intermediate
<b>Repair Cost</b>	:	\$150-\$500	
<b>Can I Still Drive?</b>	:	No	

### What Does The P032B Code Mean?

Knock sensors are used to detect engine pre-detonation (engine knock or ping). The knock sensor(KS) is usually a two wire sensor. A 5 volt reference is supplied to the sensor and there is a signal return from the knock sensor to the PCM (powertrain control module).

For this DTC it refers to the #3 knock sensor, refer to a vehicle specific service manual for the specific location. If there are multiple banks of the engine, this is the bank of cylinders that contains cylinder #1.

The sensor signal wire informs the PCM when a knock occurs and in what degree of severity. The PCM will retard the spark timing to avoid pre-detonation.

Most PCMs have the ability to learn spark knock trends in the engine during normal operation.

If the PCM determines that the knock is out of the ordinary or that the noise level is abnormally high, P032B may set. If the PCM senses that the knock is severe and cannot be eliminated by retarding the spark timing, P032B may set.

Keep in mind that knock sensors cannot distinguish between a knock from pre-detonation or one from engine problems.

## What Are The Symptoms Of The P032B Code?

Symptoms of a P032B DTC may include:

- MIL (Malfunction Indicator Lamp) illumination
- Audible knocking from the engine compartment
- Pinging from engine under acceleration

## What Are The Potential Causes Of The P032B Code?

Potential causes of a P032B code include:

- Knock sensor has failed
- Knock sensor connector is damaged
- Knock sensor circuit is open or shorted to ground
- Knock sensor circuit is shorted to voltage
- Moisture in knock sensor connectors
- Incorrect fuel octane
- PCM has failed

## How Can You Fix The P032B Code?

### Step 1

If an engine knock can be heard, fix the source of the mechanical problem first then retest. Make sure the proper octane of fuel was used in the engine. Using lower octane fuel than what is specified can cause a ping or pre-detonation and may cause P032B.

### Step 2

Unplug the knock sensor and check for water or corrosion in the connector. If the knock sensor has a seal, verify there is no coolant from the engine block fouling the sensor. Repair as necessary.

### Step 3

Turn ignition to run position with engine off. Ensure that 5 Volts are present at the KS #3 connector. If there is, check for proper resistance between KS terminal and engine ground. You will need a vehicle specification for this.

If resistance is out of specification, replace the knock sensor. If resistance is normal, plug KS back in and idle the engine. Using a scan tool in data stream, observe KS value. Does it indicate a knock is present at idle?

If so, replace the knock sensor. If the knock sensor shows no knock at idle, then tap on the engine

block while observing the knock signal. If it doesn't show a signal that corresponds with the taps, replace the knock sensor.

If it does, verify the knock sensor wiring isn't routed next to ignition wires. If there was no 5 volts present at the knock sensor connector while unplugged with KOEO (Key on engine off) then go back to the PCM connector.

## Step 4

Turn ignition off and clip the knock sensor 5 volt reference wire in a location that is easy to repair (Or remove the wire from the PCM connector). With KOEO, check for 5 volts on the PCM side of the clipped wire. If 5 volts isn't present, suspect a bad PCM. If 5 volts IS present, repair short in 5 volt reference circuit.

Since the reference circuit is a shared circuit, you will need to check all engine sensors that are fed a 5 volt reference. Unplug each sensor one at a time until the reference voltage returns. When it returns the last sensor you plugged in is the shorted sensor. If no sensors are shorted, check the wiring harness for short to voltage on reference circuit.

## Reference Sources

[P032B: Knock Sensor Circuit Voltage](#), OBD-Codes.