

P040B: EXHAUST GAS RECIRCULATION TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$200-\$300
Can I Still Drive?	:	No

What Does The P040B Code Mean?

Before the EGR (Exhaust Gas Recirculation) systems were effectively introduced to vehicles in the 1970's, engines were actively wasting unburned fuel and expelling it to the atmosphere. These days on the other hand, a vehicle has to have a certain emission rating in order to proceed with production.

The use of EGR systems has greatly improved emissions by recirculating fresh exhaust coming from the exhaust manifold and/or other parts of the exhaust system and recycling or re-burning it to make sure we are efficiently burning the fuel that we pay for with our hard earned cash!

The function of the EGR temperature sensor is essentially to provide a means for the ECM (Engine Control Module) to monitor the temperature within the EGR system and/or adjust flow accordingly using the EGR valve. It does this easily using a common temperature sensitive resistor-type sensor.

Your OBD (On-Board Diagnostic) scan tool may show P040B and associated codes active when the ECM detects a fault within the EGR temperature sensor or it's circuits. As I mentioned earlier, the system involves the exhaust which is hot, not only that but you are dealing with one of the hottest areas of the vehicle so be aware of where your hands/fingers are even with the engine off for a short period of time.

The code P040B Exhaust Gas Recirculation Temperature Sensor A Circuit Range/Performance is set

by the ECM when there is a detected out of range condition or functionality issue within the EGR Temperature Sensor "A" circuit. Refer to a vehicle specific repair manual to determine which is the "A" part of the circuit for your particular application.

What Are The Symptoms Of The P040B Code?

Symptoms of a P040B trouble code may include:

- Failed smog or emissions state/provincial test
- Engine noise (knocking, rattling, pinging, etc.)
- Louder exhaust
- Excessive exhaust smells

What Are The Potential Causes Of The P040B Code?

Causes for this P040B engine code may include:

- Defective or damaged EGR (Exhaust Gas Recirculation) temperature sensor
- EGR temperature sensor gasket leaking
- Cracked or leaking exhaust pipe in which the sensor is mounted
- Burnt wiring harness and/or sensor
- Damaged wire(s) (open, short to power, short to ground, etc.)
- Damaged connector
- ECM (Engine Control Module) issue
- Poor connections

How Can You Fix The P040B Code?

Basic Step #1

First thing I would do here is check for anything we can see by just visually inspecting the sensor and surrounding EGR system, looking for exhaust leaks in particular. Also check out the sensor and its harness while your in there. Remember what i said about those high temps? They can cause havoc on plastic and rubber insulated wires so inspect them thoroughly.

TIP: Black soot may indicate an exhaust leak around the area.

Basic Step #2

A lot of EGR issues I've seen in the past has been caused by accumulated soot in the exhaust potentially caused by a number of things (poor maintenance, low quality fuel etc.). In this case, it is not an exception, so it may be good to clean your EGR system or at the very least the temperature sensor.

Be aware that sensors mounted within the exhaust systems may feel like they are seized when trying to unfasten.

Remember, these sensors are subject to substantial temperature fluctuations, so a bit of heat using an Oxyacetylene torch (not for the layman) may help loosen the sensor. Once sensor is removed, use carburetor cleaner or similar product to effectively soak the soot. Use a wire brush to loosen soot in any overly accumulated areas. When reinstalling the clean sensor, make sure to apply some anti-seize to the threads to aid in preventing seizing.

NOTE: The last thing you want to do here is break the sensor inside the manifold/exhaust. This could be an expensive mistake so take it easy when cracking free the sensor.

Basic Step #3

Verify the integrity of the sensor by measuring actual electrical values compared to manufacturer specific desired values. Do this using your multimeter and following manufacturer specific pin-out test procedures.

Severity Description

Severity here varies significantly depends on your particular issue but I wouldn't classify this as severe given the fact that the entire system was introduced to vehicles simply as an emission reduction strategy. That being said exhaust leaks aren't "good" for your vehicle nor are leaking or defective EGR temp sensors so maintenance is the key here, sooner rather than later!

An example of an EGR temperature sensor:

Reference Sources

[P040B EGR Temp Sensor A Circuit Range](#), OBD-Codes.