

P0563: SYSTEM VOLTAGE HIGH

OVERVIEW

Severity	:	High
DIY Difficulty Level	:	Advanced
Repair Cost	:	\$500-\$2500
Can I Still Drive?	:	No

What Does The P0563 Code Mean?

The PCM controls the charging system to a certain extent on these vehicles. The PCM can control the charging system by controlling a power or a ground circuit to the voltage regulator inside the alternator.

The Powertrain Control Module (PCM) monitors the ignition feed circuit to determine if the charging system is working. If the voltage is too high, a fault code will be set. This is strictly an electrical issue.

Troubleshooting steps may vary depending upon manufacturer, type of charging system control and wire colors.

What Are The Symptoms Of The P0563 Code?

Symptoms of a P0563 engine code may include:

- Malfunction Indicator Light On
- Red battery light On
- Transmission may not shift
- Engine may not start or if it does start, may stall out and die
- Lower fuel economy

What Are The Potential Causes Of The P0563 Code?

Potential causes for this code to set are:

- High resistance in the cable between the alternator and battery – possible
- Low resistance/open circuit between the alternator and the control module – possible
- Alternator faulty – most common
- Failed PCM – unlikely

How Can You Fix The P0563 Code?

Check For Technical Service Bulletins

A good starting point is always to check for technical service bulletins (TSB) for your particular vehicle. Your issue may be a known issue with a known fix put out by the manufacturer and can save you time and money during diagnosis.

Check The Charging System

The most common cause for this code is low battery voltage/a battery that was disconnected/charging system malfunction (faulty alternator). While we are on the subject, let's not forget to check the most neglected part of the charging system, the alternator belt!

First, check the charging system. Start the vehicle. Turn the headlights on and blower fan to High speed to load the electrical system. Using a Digital Volt Ohm Meter (DVOM), check voltage at the battery. It should be between 13.2 volts and 14.7 volts. If the voltage is above 15.5 volts, diagnose the charging system, with the main emphasis being on the alternator. If unsure, have the battery, starting and charging system tested at a local parts store / auto repair shop. Most will perform this service for a small charge, if not for free, and will usually give you a printout of the test results.

Clear The Diagnostic Trouble Codes

If the voltage was correct, and you have a scan tool, clear the diagnostic trouble codes from memory, and see if this code returns. If it does not, more than likely this code is either intermittent or is a history/memory code and no further diagnosis is required.

Check The Voltages To The PCM

If the P0563 code does return, locate the PCM on your particular vehicle. Once located, visually inspect the connectors and wiring. Look for scraping, rubbing, bare wires, burn spots or melted plastic. Pull the connectors apart and carefully inspect the terminals (the metal parts) inside the connectors.

See if they look burned or have a green tint indicating corrosion. Use electrical contact cleaner and a plastic bristle brush if cleaning of the terminals is needed. Let dry and apply electrical grease where the terminals contact.

Next, clear the diagnostic trouble codes from memory with the scan tool, and see if this code returns. If it does not, then the connections were most likely your problem.

If the P0563 code does return, we will need to check the voltages to the PCM. First, disconnect the negative battery cable at the battery. Next, disconnect the harness going to the PCM. Reconnect the battery cable. Turn the ignition switch on.

With a DVOM, test the PCM ignition feed circuit (Red lead to the PCM ignition feed circuit, black lead to a good ground). If there is less than battery volts on this circuit, repair the wiring from the PCM to the ignition switch.

If that's OK, check to make sure you have a good ground at the PCM. Connect a test light to 12V battery positive (red terminal) and touch the other end of the test light to the ground circuit going to the PCM ignition feed circuit ground. If the test light does not light up, this would indicate the problem circuit. If it does light up, wiggle the wiring harness going to the PCM to see if the test light flickers, indicating an intermittent connection.

If all prior tests have passed and you continue to get a P0563, this would most likely indicate a failed PCM. If unsure, seek assistance from a trained automotive diagnostician. PCMs must be programmed, or calibrated to the vehicle in order to be installed correctly.

Reference Sources

[Diagnostic Trouble Code \(DTC\) Guide for P0563](#) - Ominitek Advanced Technologies, pages 119-120.