

## ACURA B1032: MICU LOST COMMUNICATION WITH THE SRS UNIT (CDS MESSAGE)

### OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	<b>Yes</b> (Short-term only)

### What Does The Acura B1032 Code Mean?

This code indicates poor communication with the SRS Unit.

### What Are The Potential Causes Of The Acura B1032 Code?

Below are some possible causes of this DTC:

- If DTC B1011 is indicated with DTC B1032, check for an open in the wire between the MICU and the gauge control module.
- Gauge control module connectors terminals are bent, loose or corroded
- Poor Grounds
- "Open" or "Shorted" wires
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box
- Faulty Gauge Control Module

### Reference Sources

[Acura B1032](#), DTCDECODE.