

ACURA B1080: POWER SUPPLY CIRCUIT (IG1 LINE) INPUT ERROR FOR RELAY CONTROL MODULE AND MICU

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Advanced</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes

What Does The Acura B1080 Code Mean?

Ignition Key Switch Circuit "Open".

What Are The Potential Causes Of The Acura B1080 Code?

- Blown fuse in the under-dash fuse/relay box
- Loose or poor connections between the under-hood fuse/relay box and the under-dash fuse/relay box
- "Open" voltage circuit between the under-hood fuse/relay box and the under-dash fuse/relay box
- Faulty grounds
- Faulty relay control module; replace the under-hood fuse/relay box

Reference Sources

[Acura B1080](#), DTCDECODE.