

ACURA B1808: POWER SEAT CONTROL UNIT LOST COMMUNICATION WITH GAUGE CONTROL MODULE (A/T MESSAGE)

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes

What Does The Acura B1808 Code Mean?

Poor communication between the Power Seat Control Unit and the Gauge Control Module.

NOTE: If you are troubleshooting multiple DTCs, be sure to follow the instructions in B-CAN System Diagnosis Test Mode A.

If DTCs [B1011](#), [B1060](#), [B1061](#), [B1205](#), [B1357](#), [B1359](#), [B1408](#), [B1805](#), [B1806](#), [B1906](#), and [B2160](#) are also indicated, perform the gauge control module input test.

If no addition codes are present, replace the Power Seat Control Unit.

What Are The Potential Causes Of The Acura B1808 Code?

- Loose or poor connections between the Power Seat Control Unit and the Gauge Control Module
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box
- "Open or "Short" Condition between the Power Seat Control Unit and the Gauge Control Module
- Faulty Power Seat Control Unit

- Faulty Gauge Control Module

Reference Sources

[Acura B1808](#), DTCDECODE.