

ACURA B1837: DRIVING POSITION MEMORY RECALL TIMEOUT

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Advanced</div></div>
Repair Cost	:	\$80-\$150
Can I Still Drive?	:	Yes (Short-term only)

What Does The Acura B1837 Code Mean?

This code indicates Driving Position Memory Recall Timeout.

NOTE: If you are troubleshooting multiple DTCs, be sure to follow the instructions in B-CAN System Diagnosis Test Mode A.

What Are The Potential Causes Of The Acura B1837 Code?

Below are some possible causes of this DTC:

- Check for loose or poor connections
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box

Severity Description

Check possible solutions below:

- Perform the following motor tests. Power tilt/telescopic motor test, Power mirror actuator test, Power seat motor test.
- Perform the following input tests. Power seat control unit input test, Power tilt/telescopic steering control unit input test, Driver's MPCS unit input test.

Reference Sources

[Acura B1837](#), DTCDECODE.