

## ACURA B1906: IMMOBILIZER-KEYLESS CONTROL UNIT LOST COMMUNICATION WITH GAUGE CONTROL MODULE (A/T MESSAGE)

### OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes

### What Does The Acura B1906 Code Mean?

Poor communication between the Immobilizer-Keyless Control Unit and the Gauge Control Module.  
Poor communication between the Immobilizer-Keyless Control Unit and the Gauge Control Module.

**NOTE:** If you are troubleshooting multiple DTCs, be sure to follow the instructions in B-CAN System Diagnosis Test Mode A. If DTCs [B1061](#), [B1359](#), [B1808](#), and [B1956](#) are also indicated, perform the Gauge Control Module input test. If no codes are present, perform the Immobilizer-Keyless Control Unit input test.

### What Are The Potential Causes Of The Acura B1906 Code?

- Loose or poor connections between the Immobilizer-Keyless Control Unit and the Gauge Control Module
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box
- "Open" or "Short condition
- Poor ground
- Faulty Gauge Control Module
- Faulty Immobilizer-Keyless Control Unit

## Reference Sources

[Acura B1906](#), DTCDECODE.