

## ACURA P1154: HO2S-21 (BANK 2 SENSOR 1) TRANSITION TIME RATIO

### OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$100-\$200
Can I Still Drive?	:	Yes

### What Does The Acura P1154 Code Mean?

DTC P0101, P0102, P0103, P0106, P0107, P0108, P0117, P0118, P0121, P0122, P0123, P0131, P0132, P0133, P0134, P0135, P0300, P0301-P0306, P0441 and P1441 not set, system voltage from 10-16v, engine speed from 1500-3000 rpm in closed loop for 1 minute, ECT s

### What Are The Potential Causes Of The Acura P1154 Code?

- Air leaks at the exhaust manifold or exhaust pipes
- HO2S signal circuit is open or shorted to ground (intermittent)
- HO2S heater power circuit is open, or the heater has failed
- HO2S contaminated with wrong fuel, has deteriorated or failed

### Reference Sources

[Acura P1154](#), DTCDECODE.