

What Does The Acura P1362 Code Mean?

Engine cranking or running; and the PCM did not receive any signals from the Top Dead Center 1 (TDC1) sensor during the CCM test.

Note: The engine will start and run without the TDC sensor 1 signal.

What Are The Potential Causes Of The Acura P1362 Code?

- TDC1 signal circuit is open or shorted to ground
- TDC1 pickup assembly or its pulse rotor is damaged
- TDC1 is damaged or has failed
- PCM has failed

Reference Sources

2001 Engine Performance Acura Self-Diagnostics, MDX, 3.2CL & 3.2TL, page 38.

