

What Does The Acura P1367 Code Mean?

Engine cranking or running; and the PCM did not detect any signals from the Top Dead Center 2 (TDC2) sensor during the CCM test.

Note: The engine will start and run without the TDC sensor 2 signal.

What Are The Potential Causes Of The Acura P1367 Code?

- TDC2 signal circuit is open or shorted to ground
- TDC2 pickup assembly or its pulse rotor is damaged
- TDC2 is damaged or has failed
- PCM has failed

Reference Sources

Acura P1367, DTCDECODE.

