

What Does The Acura P1740 Code Mean?

This code indicates the condition that engine running in gear, and the PCM detected an unexpected voltage condition on the 4th pressure switch circuit during the test.

What Are The Potential Causes Of The Acura P1740 Code?

Below are some potential causes of this DTC:

- A/T 4th pressure switch signal circuit is open
- A/T 4th pressure switch signal circuit is shorted to ground
- A/T 4th pressure switch signal circuit shorted to system power
- A/T 4th pressure switch is damaged or has failed
- TCM or PCM has failed

Reference Sources

Acura P1740, DTCDECODE.

