

## What Does The Acura P1773 Code Mean?

This code indicates the condition that vehicle driven in 1st, 2nd, 3rd and 4th gears, and the PCM detected an unexpected voltage condition on the Solenoid 'B' control circuit.

**Note:** The D4 lamp on the dash will blink when this code is set.

## What Are The Potential Causes Of The Acura P1773 Code?

Below are some potential causes of this DTC:

- Lockup solenoid 'B' control circuit is open or shorted to ground
- Lockup solenoid 'B' circuit is shorted to system power
- Lockup solenoid 'B' is damaged or has failed
- TCM or PCM has failed

## **Reference Sources**

Acura P1773, DTCDECODE.

