

What Does The Audi P1129 Code Mean?

Engine started, battery voltage must be at least 11.5v, all electrical components must be off, the ground between the engine and the chassis must be well connected, the exhaust system must be properly sealed between the catalytic converter and the cylinder.

What Are The Potential Causes Of The Audi P1129 Code?

- Air intake system leaking, vacuum hoses leaking or damaged
- Air leaks located after the MAF sensor mounting location
- EGR valve sticking, EGR diagramleaking, or gasket leaking
- EVAP vapor recovery system has failed

Reference Sources

- Audi of Ameria, 2013, Technical Service Bulletin.
- Audi of Ameria, 2012, Technical Service Bulletin.
- Audi of Ameria, 2013, Technical Service Bulletin.

