

What Does The Audi P1217 Code Mean?

This code is set in this condition:

Key on or engine running, fuses in the instrument panel and the E-box in the engine compartment must be functioning, and the ground connections between the engine ad the chassis must be well connected; and the ECM detected an unexpected voltage condition.

What Are The Potential Causes Of The Audi P1217 Code?

Below are some potential causes of this DTC:

- Injector control circuit is open
- Injector power circuit (B+) is open
- Injector control circuit is shorted to chassis ground
- Injector is damaged or has failed
- ECM is not connected or has failed
- Fuel pump relay has failed
- Engine speed sensor



Reference Sources

Audi P1217, DTCDECODE.

