

## What Does The Audi P1327 Code Mean?

Engine started, battery voltage at least 11.5v, all electrical components off, ground connections between engine and chassis well connected, and the ECM detected the Knock Sensor signal was more than the calibrated value.

## What Are The Potential Causes Of The Audi P1327 Code?

- Knock sensor circuit is open
- Knock sensor circuit is shorted to ground, or shorted to power
- Knock sensor is damaged or it has failed
- Poor fuel quality
- Loosen knock sensors and tighten again to 20 Nm
- ECM has failed

## **Reference Sources**

Audi A4 Avant 95-01 Service Repair Manual, page 46.

