

AUDI P1393: IGNITION COIL POWER OUTPUT STAGE 1 ELECTRICAL MALFUNCTION

OVERVIEW

Severity	:	High
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$150-\$300
Can I Still Drive?	:	No

What Does The Audi P1393 Code Mean?

Key on or Engine started, battery voltage at least 11.5v, all electrical components off, ground connections between engine and chassis well connected, parking brake must be engaged (to keep daytime driving lights off), automatic transmission selector must

What Are The Potential Causes Of The Audi P1393 Code?

- Fuel pump relay faulty
- Camshaft position sensor has failed
- Engine speed sensor has failed
- Circuit wires have shorted to ground or are open
- Ignition coils with power output stages are faulty
- ECM has failed

Reference Sources

[Audi P1393](#), DTCDECODE.