

AUDI P1398: ENGINE RPM SIGNAL, TD SHORT TO GROUND

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$200-\$300
Can I Still Drive?	:	Yes

What Does The Audi P1398 Code Mean?

Key on or Engine started, battery voltage at least 11.5v, all electrical components off, ground connections between engine and chassis well connected, parking brake must be engaged (to keep daytime driving lights off), automatic transmission selector must

What Are The Potential Causes Of The Audi P1398 Code?

- Can-bus signal faulty
- Speed sensor has failed

Reference Sources

[Audi P1398](#), DTCDECODE.