

What Does The Audi P1515 Code Mean?

Engine started, and the ECM detected the changeover valve circuit was shorting to ground during the continuous self test.

What Are The Potential Causes Of The Audi P1515 Code?

- Leaky vacuum reservoir, vacuum lines loose or damaged
- Vacuum solenoid or vacuum actuator is damaged
- IMRC actuator cable/gears are seized, or the cables are improperly routed or seized
- IMRC housing return springs are damaged or disconnected

Reference Sources

Audi P1515, DTCDECODE.

