

## What Does The Audi P1522 Code Mean?

This code indicates the condition that key on or engine running; and the ECM detected the intake manifold control signal for was outside of its expected calibrated range.

## What Are The Potential Causes Of The Audi P1522 Code?

Below are some potential causes of this DTC:

- Camshaft control circuit is open or shorted to ground
- Camshaft sensor is damaged or the ECM has failed
- Camshaft out of adjustment

## **Reference Sources**

Omnitek Engineering Corp., 2006, <u>Diagnostic Trouble Code (DTC) Guide for Omnitek ECM 64A/66A/88A</u>, page 137.

