

AUDI P3032: THROTTLE ACTUATOR BASIC SETTING

BANK 1 BANK 2

OVERVIEW

Severity	:	 High
DIY Difficulty Level	:	 Advanced
Repair Cost	:	\$400-\$900
Can I Still Drive?	:	No

What Does The Audi P3032 Code Mean?

Condition for setting the DTC:

Fuel cutoff active throttle position setpoint limitation inactive Engine speed, \leq 300 RPM IAT, $>5^\circ$ C
Vehicle speed, \leq 0 MPH ECT, \geq 5.3° C IAT \geq 5.3° C

Reference Sources

- Audi, 2013, [A8/A8L/S8 Quick Reference Specification Book](#), page 301.
- Audi, 2013, [R8/Spyder Quick Reference Specification Book](#), page 142.