BMW P1034: VALVETRONIC (VVT) ACTUATOR MONITORING RECOGNITION OF DIRECTION OF ROTATION PLAUSIBILITY (BANK 1)

OVERVIEW

Severity : High

DIY Difficulty Level : Advanced

Repair Cost : \$300-\$450

Can I Still Drive? : Yes (Short-term only)

What Does The BMW P1034 Code Mean?

This code indicates the condition that the engine is on and running for 63 to 498ms at 9.6 to 15.5 volts. Check to determine whether adjustment can be approved. Check VVT system once before each power application within one driving cycle for correct servo motor polarity and sticking in the system.

What Are The Potential Causes Of The BMW P1034 Code?

Below are some potential causes of this DTC:

- Low battery charge
- Open motor control circuit
- Motor shorted to ground
- Loose sensor or it is operating at the limit

Reference Sources

BMW P1034, DTCDECODE.

