

BMW P1132: HO2S (BANK 2 SENSOR 1) HEATER CIRCUIT MALFUNCTION

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$100-\$200
Can I Still Drive?	:	Yes

What Does The BMW P1132 Code Mean?

Engine running, battery voltage 11.5, all electrical components disconnected, ground between engine and chassis securely connected, and exhaust system sealed between catalytic converter and cylinder head. DME has detected an open or short circuit.

What Are The Potential Causes Of The BMW P1132 Code?

- HO2S heater power circuit is open
- HO2S heater ground circuit is open
- HO2S signal tracking (due to oil or moisture in the connector)
- HO2S is damaged or has failed

Reference Sources

[BMW Fault Codes \(DTCs\)](#), page 11.