

BMW P1136: HO2S HEATER CIRCUIT HEATER RESISTANCE

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$100-\$200
Can I Still Drive?	:	Yes

What Does The BMW P1136 Code Mean?

Engine running, battery voltage 11.5, all electrical components off, ground between engine and chassis well connected and the exhaust system must be properly sealed between catalytic converter and the cylinder head.

What Are The Potential Causes Of The BMW P1136 Code?

- HO2S heater power circuit is open
- HO2S heater ground circuit is open
- HO2S signal tracking (due to oil or moisture in the connector)
- HO2S is damaged or has failed

Reference Sources

[BMW P1136](#), DTCDECODE.