

What Does The BMW P1414 Code Mean?

The Engine Control Module detects a short circuit when activating the secondary air injection solenoid valve.

Note: Solenoid valve is closed when no voltage is present.

What Are The Potential Causes Of The BMW P1414 Code?

- Connector to the secondary air injection valve is loose or disconnected
- Secondary air injector valve circuit short
- Secondary air injector valve circuit is open
- Faulty secondary air injector valve

Reference Sources

BMW P1414, DTCDECODE.

