

What Does The BMW P1418 Code Mean?

The Engine Control Module detects an implausible signal when activating the secondary air injection solenoid valve. The secondary air valve or tube is blocked.

Note: Solenoid valve is closed when no voltage is present.

What Are The Potential Causes Of The BMW P1418 Code?

- Connector to the secondary air injection valve is loose or disconnected
- Secondary air injector valve circuit short
- Secondary air injector valve circuit is open
- Faulty secondary air injector valve

Reference Sources

BMW P1418, DTCDECODE.

