BMW P1502: IDLE AIR CONTROL VALVE CIRCUIT SHORT TO B+			
		OVERVIEW	
Severity	:	Medium	
DIY Difficulty Level	:		Advanced
Repair Cost	:	\$120-\$500	
Can I Still Drive?	:	Yes (Short-term only)	

What Does The BMW P1502 Code Mean?

Engine running the DME detected that the idle air control valve was intermittent.

What Are The Potential Causes Of The BMW P1502 Code?

Below are some potential causes of this DTC:

- Fuel delivery unit connector is loose or not attached
- Fuse 18 cause a short to the transfer fuel pump or the O2S
- Fuel pump has failed
- Fuel pump relay circuit is shorted to ground, B+ or is open
- Fuel Pump (FP) Relay not activated

Reference Sources

BMW P1502, DTCDECODE.

