/IEW
Medium
Advanced
)-\$500
0

What Does The BMW P1503 Code Mean?

Engine running the DME detected that the idle air control valve was intermittent.

What Are The Potential Causes Of The BMW P1503 Code?

- Fuel delivery unit connector is loose or not attached
- Fuse 18 cause a short to the transfer fuel pump or the O2S
- Fuel pump has failed
- Fuel pump relay circuit is shorted to ground, B+ or is open
- Fuel Pump (FP) Relay not activated

Reference Sources

BMW P1503, DTCDECODE.

