

What Does The BMW P1520 Code Mean?

After 60 seconds with the ignition on, a miscommunication between the oil sensor and the DME was detected.

What Are The Potential Causes Of The BMW P1520 Code?

- Replace the oil temperature sensor
- Check BSD wire, voltage supply and oil level sensor ground for an open circuit. If okay, replace the oil level sensor.

Reference Sources

BMW Fault Codes (DTCs), page 5.

