

## What Does The BMW P1532 Code Mean?

Engine started and driven at an engine speed of more than 400rpm; and the DME detected the camshaft timing exceeded the calibrated levels. The valve timing did not change from the current valve timing or it remained fixed during the testing.

## What Are The Potential Causes Of The BMW P1532 Code?

Below are some potential causes of this DTC:

- Fuel pump has failed
- CPS circuit is open, shorted to ground or shorted to power

## **Reference Sources**

BMW P1532, DTCDECODE.

