HOME POSITION UNKNOWN			
		OVERVIEW	
Severity	:		High
DIY Difficulty Level	:	Adv	anced
Repair Cost	:	\$600-\$850	
Can I Still Drive?	:	Yes	

What Does The BMW P1633 Code Mean?

Engine started, and the battery voltage is greater than 7 volts, this fault is only diagnosed during the throttle valve's adaptation phase.

What Are The Potential Causes Of The BMW P1633 Code?

- Plate is sticking
- Defective return spring
- DVE electrical activation defective.
- DVE motor wiring may have shorted
- Throttle valve is contaminated with foreign objects
- Defective throttle-valve actuator motor
- Throttle valve seized in open or fully-closed position

Severity Description

Check on throttle valve's emergency default position as determined during throttle valve adaptation.



Reference Sources

ENGINE PERFORMANCE Self Diagnosis for P1633 - 2011 BMW 535xi, pages 48-50.

