

BMW P1667: EWS (ELECTRONIC IMMOBILIZER) START VALUE NOT YET PROGRAMMED

OVERVIEW

Severity	:	<div style="width: 50%;">Medium</div>
DIY Difficulty Level	:	<div style="width: 50%;">Intermediate</div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes (Short-term only)

What Does The BMW P1667 Code Mean?

Key on the DME detected an electrical malfunction regarding the EWS. Check the EWS fuse, the ECU or CAN for fault, turn the ignition off and then on to repeat start calibration.

What Are The Potential Causes Of The BMW P1667 Code?

Below are some potential causes of this DTC:

- Circuit from the MIL to the DME
- ECU Failure, BUS system failure
- Circuit from the EPC to the DME
- Defective CAS

Reference Sources

[BMW P1667](#), DTCDECODE.