

BMW P1727: ENGINE SPEED SIGNAL PLAUSIBILITY

OVERVIEW

Severity	:	<div><div>High</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$450
Can I Still Drive?	:	Yes

What Does The BMW P1727 Code Mean?

The CAN Message signal error flag alive counter or check sum is sending/receiving an incorrect signal. There is no alteration of the alive counter and no wrong check sum. The DME-CAN Connection is okay. The CAN-Bus is okay and the ignition is on.

What Are The Potential Causes Of The BMW P1727 Code?

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

Reference Sources

[BMW P1727](#), DTCDECODE.