

What Does The BMW P1728 Code Mean?

The engine speed is over 10,000rpm. The range position is D, and the park-lock sensor is okay.

What Are The Potential Causes Of The BMW P1728 Code?

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

Reference Sources

BMW P1728, DTCDECODE.