

What Does The BMW P1762 Code Mean?

The shift solenoid valve is shorting to power after 50ms of operation.

What Are The Potential Causes Of The BMW P1762 Code?

Below are some potential causes of this DTC:

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

Reference Sources

BMW P1762, DTCDECODE.

