

## What Does The BMW P1763 Code Mean?

The shift solenoid valve is shorting to ground after 50ms of operation.

## What Are The Potential Causes Of The BMW P1763 Code?

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

## **Reference Sources**

BMW P1763, DTCDECODE.