OVERVIEW		
Severity	:	Hig
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$75-\$450
Can I Still Drive?	:	Yes (Short-term only)

What Does The BMW P1801 Code Mean?

The signal to/from the pressure regulator valve is interrupted or short circuited to ground.

What Are The Potential Causes Of The BMW P1801 Code?

Below are some potential causes of this DTC:

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

Reference Sources

BMW P1801, DTCDECODE.

