

What Does The BMW P1803 Code Mean?

The signal to/from the pressure regulator valve is interrupted or short circuited to ground.

What Are The Potential Causes Of The BMW P1803 Code?

- Pressure control solenoid circuit is shorting to ground
- Pressure control solenoid circuit is open
- Valve has failed
- TCM has failed

Reference Sources

BMW P1803, DTCDECODE.