

What Does The BMW P1811 Code Mean?

Engine started, vehicle driven with the vehicle speed sensor indicating more than 1 mph, and the DME detected the Transmission Vehicle Speed Sensor signals were erratic, or that they were missing for a period of time. The engine speed is greater than 600rpm

What Are The Potential Causes Of The BMW P1811 Code?

- TVSS signal circuit is open
- TVSS signal is shorted to chassis ground
- TVSS signal is shorted to sensor ground
- TVSS assembly is damaged or it has failed

Reference Sources

BMW P1811, DTCDECODE.

