

## BMW P1883: 3-4 SHIFT UPPER THRESHOLD

### OVERVIEW

<b>Severity</b>	:	Medium	
<b>DIY Difficulty Level</b>	:	Intermediate	
<b>Repair Cost</b>	:	\$200-\$500	
<b>Can I Still Drive?</b>	:	Yes	

### What Does The BMW P1883 Code Mean?

Engine running and vehicle driven, the DME detected a mechanical malfunction within the transmission. The ratio of the input speed minus the output speed is greater than the threshold value. The output speed is greater than 300rpm.

### What Are The Potential Causes Of The BMW P1883 Code?

- Solenoid valves in valve body are faulty
- Solenoid circuit is shorting to ground
- Solenoid circuit is open
- TCM has failed or wiring is shorting
- Mechanical malfunction in transmission

### Reference Sources

[BMW P1883](#), DTCDECODE.