

BMW P3232: CONTROL MODULE MONITORING IGNITION TIMING PLAUSIBILITY

OVERVIEW

Severity	:	High
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$100-\$600
Can I Still Drive?	:	No

What Does The BMW P3232 Code Mean?

Key on, engine running to at least 1200rpm, the DME has detected an internal fault in the computer or internal fault in the control modules. The Torque monitoring feature compares the torque demand (from accelerator pedal, FGR, electrical equipment).

What Are The Potential Causes Of The BMW P3232 Code?

- Battery terminal corrosion, loose battery connection, or faulty
- Connection to the DME interrupted, or the circuit has been opened
- Reprogramming error has occurred

Reference Sources

[BMW P3232](#), DTCDECODE.