

CADILLAC P1400: COLD START EMISSION REDUCTION CONTROL SYSTEM

OVERVIEW

Severity	:	High
DIY Difficulty Level	:	Advanced
Repair Cost	:	\$300-\$500
Can I Still Drive?	:	No

What Does The Cadillac P1400 Code Mean?

This code indicates that the actual exhaust energy model does not match the expected exhaust energy model.

Conditions for setting the DTC:

- DTCs P0016, P0069, P0101, P0102, P0103, P0106, P0107, P0108, P0112, P0113, P0116, P0117, P0118, P0120, P0121, P0122, P0123, P0171, P0172, P0174, P0175, P0207, P0208, P0220, P0222, P0223, P0201, P0202, P0203, P0204, P0205, P0206, P0300, P0308, P0335, P0336, P0351-P0358, P0601, P0602, P0603, P0604, P0606, P0607, P060D, P062F, P0641, P0651, P1101, P1516, P1682, P2101, P2119, P2120, P2122, P2123, P2125, P2127, P2128, P2135, P2138, P2176 are not set.
- The engine is running, and a cold start has been detected.
- Vehicle speed is less than 2 km/h (1 mph).
- The engine is at idle with no input from the accelerator pedal for greater than 5 s.
- This DTC runs for 15 s within the first 2 min of start-up.
- This diagnostic runs once per trip when a cold start has been determined.

Reference Sources

[Cadillac P1400](#), DTCDECODE.