

CADILLAC P1560: TRANSAXLE NOT IN DRIVE - CRUISE CONTROL DISABLED

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes

What Does The Cadillac P1560 Code Mean?

Engine started; Cruise Control requested and engaged, and the PCM detected the shift lever indicated Neutral, or that the Transaxle Range (TR) Switch indicated "Neutral" position.

What Are The Potential Causes Of The Cadillac P1560 Code?

Review proper procedures to use to verify the shift lever is not placed in Neutral with Cruise Control "on" with the customer.

Reference Sources

GM, 2013, [Service Bulletin - Prior To Any Circuit Testing](#).