

CADILLAC P15F2: ENGINE TORQUE COMMAND CIRCUIT

OVERVIEW

Severity	:	High
DIY Difficulty Level	:	Advanced
Repair Cost	:	\$200-\$300
Can I Still Drive?	:	Yes (Short-term only)

What Does The Cadillac P15F2 Code Mean?

This code indicates that the control module has detected an internal malfunction.

Conditions for setting the DTC: The ignition is ON. The system voltage is 8-18 V. DTC U1817 is not set.

Reference Sources

[Cadillac P15F2](#), DTCDECODE.