PERFORMANCE			
		OVERVIEW	
Severity	:		High
DIY Difficulty Level	:		Advanced
Repair Cost	:	\$75-\$350	
Can I Still Drive?	:	No	

What Does The Cadillac P16F9 Code Mean?

This code indicates that the control module has detected the internal programmable logic device has not turned on or off correctly.

Conditions for setting the DTC: The ignition is ON. Ignition voltage is 8-18 V.

Reference Sources

Cadillac P16F9, DTCDECODE.

