## CHEVROLET B2722: TRANS PREFERENCE SWITCH CIRCUIT LOW

**OVERVIEW** 

Severity : Medium

DIY Difficulty Level : Intermediate

**Repair Cost** : \$75-\$200

**Can I Still Drive?** : Yes (Short-term only)

## What Does The Chevrolet B2722 Code Mean?

Conditions for setting the DTC:

- The battery voltage must be between 9.0 and 16.0 volts.
- Ignition switch in the RUN position.
- The Tow/Haul switch must be activated.

## **How Can You Fix The Chevrolet B2722 Code?**

- Perform a visual inspection for loose or poor connections at all related components.
- Refer to Testing for Intermittent and Poor Connections in Wiring Systems.

## **Reference Sources**

Chevrolet B2722, DTCDECODE.

