

## CHEVROLET C120D: TRACTION CONTROL POWER SWITCH CIRCUIT OPEN

### OVERVIEW

|                      |   |                                    |
|----------------------|---|------------------------------------|
| Severity             | : | <div><div>Medium</div></div>       |
| DIY Difficulty Level | : | <div><div>Intermediate</div></div> |
| Repair Cost          | : | \$70-\$150                         |
| Can I Still Drive?   | : | <b>Yes</b> (Short-term only)       |

### What Does The Chevrolet C120D Code Mean?

Conditions for setting the DTC: Ignition voltage is greater than 10 V. The solenoid relay is commanded ON.

### What Are The Potential Causes Of The Chevrolet C120D Code?

Below are some potential causes of this DTC:

- The EBCM detects an open in the circuits to the solenoid valve relay.
- The EBCM detects a stuck open solenoid valve relay.
- The EBCM detects an short to battery in the circuits to the solenoid valve relay.
- The EBCM detects a stuck closed solenoid valve relay.

### Reference Sources

[Chevrolet C120D](#), DTCDECODE.