

What Does The Chevrolet P159C Code Mean?

This DTC is set when PTOM detects a signal mismatch between the remote engine shut off signal and the PTO engine shutdown signal.

Conditions for setting the DTC: The engine is running and PTO is engaged.

Reference Sources

Chevrolet P159C, DTCDECODE.

