

## What Does The Chevrolet P161A Code Mean?

This DTC indicates that the glow plug control module (GPCM) is not programmed.

Conditions for setting the DTC: DTC P161A runs continuously when the ignition is ON.

## **Reference Sources**

Chevrolet P161A, DTCDECODE.

