

What Does The Chevrolet P163E Code Mean?

Conditions for setting the DTC:

The ignition is ON. DTC P163E runs continuously. The glow plug control module temperature is greater than 85°C (185°F), and the engine coolant temperature is less than 60°C (140°F).

Reference Sources

Chevrolet P163E, DTCDECODE.

